

To **Start** blue boat

Check that the **gear lever** is in **Neutral**

Neutral is found by pulling the gear lever out at right angles to the housing

Turn the **key** to '**ON**' position

While engine whistles -

Press and release the **black button**

[for **COLD** starts – rev engine while in Neutral by pushing lever forward]

Release mooring **ropes**

Move gear lever in towards housing to locate 'drive' and then push it forward or reverse for chosen direction.

To '**Stop**' blue boat

Put **gear lever** in **neutral** . Pull '**choke**'

Turn **key** to '**Off**' position

Secure mooring **ropes**